


# GoBar™ High Top Bar User Guide

## BAR SETUP:

Your GoBar™ includes the following items:

- 1 GoBar™
- 3 Interchangeable Front Skirts (Black, Football and Tiki designs)
- 1 Secondary Storage Shelf
- 1 Carrying Case

To setup, unpack the contents of the carrying case. Next, fold out both legs of the GoBar™ and make sure they lock into place. Next, place the secondary storage shelf between the 2 middle supports on the legs (as shown below). Lastly, choose a front skirt and Velcro it on to the front of the bar (side with the Velcro).



## GoBar™ Guidelines:

**Setup:** Always Setup the GoBar on a Flat and Even Surface! Failure to do so may cause the bar to tip over causing damage and injury.

**Maximum Weight on top of Bar:** 25 pounds

**Maximum Weight on Secondary Storage Shelf:** 25 pounds

**Front Skirt Care:** Front Skirt is NOT machine washable. To clean, use a damp rag and water.